

EMERGENCY STOP

Press the Propeller Lock and Takeoff & Land buttons simultaneously to trigger an Emergency Stop

In the event of an emergency stop:

- Retrieve the drone safely
- Inspect the drone, propellers, and battery for damage

